




# HOW TO OPERATE YOUR ACTIVE DOOR (LEFT HAND STACKING / OUTWARD OPENING)




## HOW TO OPERATE YOUR LEVER HANDLE



- 1.) To **Open (Main Swing)**: Push handle down at 45°, and push open. (Allow panel to click into panel catch on the adjacent panel.)



- 2.) To **Close** door pull panel shut to Latch like a typical entry way door.




- 3.) After latching pull handle **Up** at 45°, well pulling In. Then engage lock with thumb turn 360° clockwise.


## HOW TO OPERATE YOUR BI-FOLD HANDLE



- 1.) Bi-fold handle in **locked** position. (When door is closed)



- 2.) To **Open** bi-fold, pull handle up 90° and release then push out.



- 3.) To **Close** bi-fold, in one motion push handle down 90°.